Add your Smart Device to your App

4. Enter your home WiFi password.





Connection will now begin.

5. Once connected you'll get a menu **'Adding device succeeded'.**

   Select the room device and press 'Done'.

   You can click on the pen to change the device name.

6. The smart device can now be controlled by the BrilliantSmartapp.



Go to www.brilliantsmart.com.au for full instructions and features

Warranty

Brilliant Lighting warrants this product against defects in manufacture and workmanship for a period of 12 months from date of purchase. Warranty does not include damage or loss arising from incorrect installation, operation or maintenance of this product, damage caused through modification, or incorrect installation.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Any claim under this warranty must be made within 12 months of the date of purchase of the product.

Refer to our website brilliantlighting.com.au for terms and conditions and warranty claims.

This warranty is given by:

Brilliant Lighting (Aust) Pty. Ltd.
ABN 37 006 203 694
956 Stud Road Rowville, VIC 3178
Phone: 03 9765 2555
Email: warranty@brilliantlighting.com.au

MADE IN CHINA

1903 06/19 00

Warning

- Read all instructions carefully, even if you feel you are quite familiar with this unit.
- All fixed wired equipment must be installed by a qualified electrical contractor.
- Supply to remote control receiver should be connected through a switch, ie existing wall switch.
- Disconnect the power supply before working on the remote control receiver or ceiling fan.
- Install receiver into the ceiling fan canopy to ensure proper protection.
- Unit to be connected to a 230-240V 50Hz supply and used for the control of ceilings fans only.
- Do not install in damp locations. Never immerse in water or allow either component to become wet.
- This unit is for indoor use only.
- Do not modify this unit in any manner.
- Do not pull or cut the leads on the receiver.
- Take care with your unit and take care not to drop the remote or receiver.
- The battery within this unit should be replaced at least once a year to avoid leakage and subsequent damage.

IMPORTANT: DO NOT DISPOSE OF BATTERY IN FIRE.

NB: BrilliantSmart app screens may differ due to application updates & improvements

Disposal

Please dispose of this product thoughtfully once it has passed its useful life. When your smart device comes to the end of its life or you choose to update or upgrade it, please do not dispose of it with your normal household waste. Please recycle where facilities exist.

When disposing of this fitting, check with your local authority for suitable options.

Troubleshooting

Problem: Smart device does not switch ON	
Possible Cause	**Suggested Solution**
No Mains Power	Check connections, fuses and switches

Problem: Cannot link smart device with BrilliantSmart app	
Possible Cause	**Suggested Solution**
1. Modem signal weak	Place device and modem closer together
2. Router/modem/smart phone firewall is enabled	Disable firewalls on all devices
3. Internet connection is down	Contact your provider
4. BrilliantSmart app not installed correctly	Remove app and re-install

For any other problems connecting your smart device to BrilliantSmart app please visit:
www.brilliantsmart.com.au/faqs

Brilliant Lighting
956 Stud Road
Rowville Vic 3178 Australia

www.brilliantlighting.com.au

Australian Sales
T 03 9765 2555
T 1800 817 754 (interstate only)
F 03 9763 0277
E sales@brilliantlighting.com.au

New Zealand Sales
T 09 974 9618
E sales@brilliantlighting.co.nz

Brilliant SMART

WiFi Ceiling Fan Controller

99111



works with the Google Assistant · works with alexa · Works with IFTTT

USER MANUAL

Box content

Receiver x 1
Wall Transmitter x 1
AAA Batteries x 2
Hardware bag screws x 1
User Manual x 1



Wall Transmitter



Receiver

Technical Specifications

Model Number: 99111
Supply voltage: 240VAC
Max Fan power: 70W
Max light power: 100W
RF frequency: 433.9MHz
Battery: 2 x AAA
Dimensions: 75mm x 120mm (wall transmitter)
Warranty: 1 year
Security: Mac Encryption; WEP/WAPI/TKIP/AES
WiFi Standard: IEEE802.11b/g/n
System Reqs: iOS 8.0 or higher, Android 4.1 or higher

Installation


BEFORE INSTALLATION, PLEASE CHECK THAT THE LOCATION OF THE SMART WIFI CEILING FAN CONTROLLER IS WITHIN RANGE OF YOUR HOME WIFI AND THE SIGNAL IS STRONG.


MUST BE INSTALLED BY A LICENSED ELECTRICIAN.

IMPORTANT: Receiver is not designed to be used together with a fan wall controller. Wall controller should be removed and replaced with isolation switch.

Wiring Diagram – Receiver Wiring Connection

Ensure the receiver is connected correctly in accordance with the following wiring diagram.





Installation

Receiver Installation


1. Turn OFF mains power before installation.
2. Lower fan canopy to access wiring (for existing fan).
3. Connect the remote control receiver to the ceiling fan through quick connectors as per diagram to the left.
4. Set codes same both on receiver and transmitter (see below).
5. Once the connection and codes has been made, insert the receiver into the drop rod hanging bracket. The canopy is then raised to conceal the receiver and bracket.
6. Restore power, then follow WiFi setup.

Code Switch and Battery Installation

Codes are set by pushing dip switches UP or DOWN.

- It is imperative that the code entered is exactly the same for both the transmitter and receiver; otherwise the remote control will not work.
- Please note the code switch will enable you to operate a second remote controller independently. For example, if you have two ceiling fans with 2 remote control units, you can operate each ceiling fan independently by setting 2 different codes for each set of transmitter/receivers.
- Following battery installation, your remote control is ready to use.

Installation



To remove battery cover, use a small flat head screwdriver to open the latch.

Transmitter and Wall Mount Installation





Attach transmitter wall mount plate to mounting surface using fixing screws or double sided tape (included).

Connect to your WiFi

Ensure your mobile phone is connected to your 2.4GHz WiFi network.

Your mobile phone and smart device needs to be within 2 bar range of your WiFi router.

Download the BrilliantSmart App

Please download the free BrilliantSmart app from the App store or Google Play store, or scan the QR code below.



Register the BrilliantSmart App

Open the BrilliantSmart app.

For new users, register a new account or if existing user, login with your user name and password.

Configure your BrilliantSmart App

Setting up your Home

You can setup multiple homes or locations. Click **'Add Home'** button. Or click on **'Home'** top left if you are adding or modifying details then **'Home Management'** to setup your home(s), add or rename rooms and share devices.



Add your Smart Device to your App

1. On initial power-on, the smart device will be ready to pair (If smart device does not automatically pair, press the reset button for 10 seconds. The reset button is located above the DIP switch on the wall transmitter).
2. Open the BrilliantSmart App, tap **'Add Device'** (if empty room) or **'+'** to add your smart device.
3. Select **'CEILING FAN'** in the list of devices. Then press "Confirm indicator rapidly blink".

